

iGo[®] everywhere

Install	Page 2
Installation	Page 3
Instalar	Page 4
Installation	Page 5
Installazione	Page 6
Instalar	Page 7
Installatie	Page 8

User Guide

Congratulations on your iGo[®] power purchase! Universally compatible with today's most popular brands, the iGo everywhere power solution allows you to power and charge from any standard wall or in-car outlet. Lose the clutter of all those model-specific chargers and power your mobile phone, Bluetooth[®] headset, smartphone/PDA, MP3 player, portable gaming device, GPS device and more from this convenient power solution (iGo chargers and power tips sold separately).

Specifications:

AC Unit

Input Voltage: 100-240 VAC
Dimensions 82.55 x 50.80 x 25.40mm

In-car Unit

Input Voltage: 11.0-16.5 VDC
Dimensions: 92.20 x 25.40 x 25.40mm

Retractable Cable

Case Dimensions: 55.10 x 66.04 x 23.62mm
Cord Length: 1.52m


Package Contents

- AC unit
- Retractable cable
- In-car unit
- Travel organizer
- User Guide

www.iGo.com

© 2002-2009 iGo, Inc. iGo is a registered trademark of iGo, Inc. All other brand names and logos are trademarks of their respective owners. Specifications are subject to change without notice. Protected under one or more of the following patents: 5,347,211; 6,064,177; 6,643,158; 6,650,560; 6,700,808; 6,751,109; 6,775,163; 6,791,853; 6,920,056; 6,937,490; 6,976,885 and 7,153,169. Other United States and foreign patents pending.
Made in China. P/N 8040406-01 Rev. B.



Install



(light grey end of cable)


Retractable cable

1. Connect the retractable light grey cable end to either the AC or in-car unit.
2. Plug the retractable black cable end to the appropriate iGo power tip.
3. You can now connect to the device you wish to charge.



Caution: Hold one end of the cable while retracting. Do not let cable retract freely. Cable may jam on reel or whip back and forth and cause injury.

Installation




(extrémité gris clair du cordon)

Cordon rétractable

1. Connectez l'extrémité gris clair du cordon rétractable au bloc d'alimentation en CA ou en CC
2. Branchez l'extrémité noire du cordon rétractable au tip d'alimentation iGo approprié
3. Vous pouvez maintenant connecter l'appareil à recharger



Remarque :
Tirez sur le câble des deux côtés.

(extrémité noire du cordon)



Précaution: Tenez la prise lors de la rétraction du cordon. Guidez le cordon lors de sa rétraction. Le cordon peut se bloquer sur le dévidoir. Il peut également vous blesser s'il génère des mouvements rapides incontrôlés.

Instalar





Se incluye un organizador de viaje

Cavidades para power tips y cable retráctil

Precaución: Sujete el enchufe mientras se retrae el cable. No deje que el cable se retraiga libremente; podría atascarse en la bobina o golpearle y causarle heridas.

Installation





Mitgeliefertes Reiseetui

Aufbewahrungshüllen für Power-Tips und aufrollbares Kabel



Vorsicht: Halten Sie den Stecker beim Einrollen des Kabels fest. Lassen Sie das Kabel beim Einrollen nicht los. Das Kabel könnte sich sonst beim Einrollen verkleben oder unkontrolliert umherwirbeln und dabei Verletzungen verursachen.

Installazione




Attenzione: Mantenere la spina mentre si ritrae il cavo. Non lasciare il cavo ritrarsi liberamente. Il cavo potrebbe imbrogliarsi sulla bobina o volteggiare all'improvviso causando lesioni.

Instalar



Atenção: Segure a ficha enquanto puxa o cabo. Não deixe que o cabo recolha livremente. O cabo pode prender-se na bobina ou soltar-se provocando ferimentos.

Installatie



1. Sluit het uiteinde van de intrekbare lichtgrijze kabel aan op de netstroomvoorziening of op de stroomvoorziening binnen de auto
2. Sluit het uiteinde van de intrekbare zwarte kabel aan op de juiste iGo-stroomadapter
3. U kunt nu een verbinding maken met het apparaat dat u wilt opladen.



Waarschuwing: zorg ervoor dat u de stekker vasthoudt wanneer u de kabel intrekt. De kabel mag niet ongecontroleerd worden ingetrokken. Hierdoor kan de kabel in de knoop raken op de rol. Daarnaast bestaat er de kans op lichamelijk letsel als gevolg van het rondzwiepen van de kabel.