

This equipment has been designed for connection to TN and IT power systems.

Issue	Probable Cause(s)	Possible Solution(s)
Notebook is not charging	Tip was removed without unplugging	Unplug from outlet, wait 30 seconds and plug unit back into outlet
Notebook is not charging	No input or output power	• Check plug connector • Check cable connections • Check outlet circuit breaker
LED does not light	Light burned out	See above solutions
LED does not light but appears to power devices	Light burned out	See above solutions
Notebook not listed on enclosed compatibility chart	Compatibility is always changing	See www.iGo.com for current compatibility information
Device is not charging when iGo dualpower is configured	Tip not installed on Notebook Input Cord	Install tip on Notebook Input Cord

Troubleshooting

Canada Compliance

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada

Environmental Requirements

Ambient operating temperature is 0°C to 40°C
Storage temperature is -20°C to 85°C

Certifications



Product Support

We are committed to providing our customers with first-class customer service and product support. You can receive help in a variety of ways:

Sales/Customer Service: 1-888-205-0093

Technical Support: 1-800-474-7593

Web: www.iGo.com

©2002-2007 Mobility Electronics, Inc. Mobility Electronics, iGo and iGo dualpower are registered trademarks and powered up and connected is a trademark of Mobility Electronics, Inc. All other brand names and logos are trademarks or registered trademarks of their respective owners. Specifications are subject to change without notice. Protected by one or more of the following patents: 5,347,211, 6,064,177, 6,700,808, 6,643,158, 6,650,560, 6,751,109, 6,775,163, 6,791,853, 6,920,056, 6,937,490 and 6,976,885. Other United States and foreign patents pending. Made in China. P/N 8040429-01 Rev.A

Safety Features

As in your car, once connected, your battery will automatically charge regardless of whether your electronic device is turned on or off. Note: We recommend that you use iGo power adapters only with device batteries that meet or exceed the original manufacturer's specifications. CAUTION: Like the power adapter that came with your electronic device, this iGo adapter may get warm to the touch during use. This is normal. Avoid placing your iGo adapter in direct sunlight or next to heat sensitive materials.

Standard Wall Outlet: As in your car, once connected, your battery will automatically charge regardless of whether your electronic device is turned on or off. Note: We recommend that you use iGo power adapters only with device batteries that meet or exceed the original manufacturer's specifications. CAUTION: Like the power adapter that came with your electronic device, this iGo adapter may get warm to the touch during use. This is normal. Avoid placing your iGo adapter in direct sunlight or next to heat sensitive materials.

How to Use This iGo Combination Power Adapter

Your vehicle may need to be running in order to get power. If after checking the connections the LED is still not illuminated, you may need to check the vehicle's fuse. Note: In some vehicles, power to the cigarette lighter is always on. These vehicles may not require the ignition to be turned on. CAUTION: It is not recommended to have this iGo adapter connected to your electronic device when starting the engine. The power may be interrupted causing your system to reset. Air: You will need to find the in-flight power outlet in the airplane. The power outlet is usually located in the arm of your seat, typically near the same location you use to plug in headphones. It may also be located under your seat. Please ask a flight attendant for the exact location of the outlet. Once located, plug the in-flight connector into the airline power outlet.

- Reorient or relocate the receiving antenna
 - Increase the separation between the equipment and receiver
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
 - Consult the dealer or an experienced radio/TV technician for help
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Compliance for iGo dualpower® Accessory

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Mobility Electronics Inc.
17800 North Perimeter Drive, Ste. 200, Scottsdale, AZ 85255 USA
Tel: 1-480-596-0061, 1-888-205-0093; Fax: 1-480-596-0349
www.iGo.com

As in your car, once connected, your battery will automatically charge regardless of whether your electronic device is turned on or off. Note: We recommend that you use iGo power adapters only with device batteries that meet or exceed the original manufacturer's specifications. CAUTION: Like the power adapter that came with your electronic device, this iGo adapter may get warm to the touch during use. This is normal. Avoid placing your iGo adapter in direct sunlight or next to heat sensitive materials.

Standard Wall Outlet: As in your car, once connected, your battery will automatically charge regardless of whether your electronic device is turned on or off. Note: We recommend that you use iGo power adapters only with device batteries that meet or exceed the original manufacturer's specifications. CAUTION: Like the power adapter that came with your electronic device, this iGo adapter may get warm to the touch during use. This is normal. Avoid placing your iGo adapter in direct sunlight or next to heat sensitive materials.

Product Registration

Thank you for purchasing one of iGo's mobile solutions. Help us serve you better by taking a moment to register your product at www.iGo.com/register. Failure to register does not diminish your warranty rights.

Power Your mobile Phones, Smartphones/PDAs, MP3 Players, Digital Cameras and more...

So, you would like to power/charge an additional mobile electronic (ME) device? Great, iGo everywhereMAX does that too. All you need is the included iGo dualpower accessory and the appropriate tip to power/charge your notebook and a gadget at the same time (additional tips sold separately).

Package Contents

- iGo notebook power adapter
- iGo dualpower accessory
- Wall outlet cord (AC)
- Auto/Air outlet cord (DC)
- Notebook input cord
- Notebook tips (See attached hang tag for corresponding models and tips)
- Carrying case
- User Guide

Universally compatible with most popular brands, iGo everywhereMAX allows you to power/charge a notebook computer from any standard power outlet. Use the included iGo dualpower® accessory, you can simultaneously power/charge a notebook computer and a smartphone/PDA, MP3 player, digital camera and more (additional iGo power tips sold separately). Also, use the iGo dualpower accessory with the auto/air outlet cord as a standard car charger for your gadgets. No other adapters are as powerful or as versatile as the iGo line of power products.

Mobility Electronics, Inc.
17800 North Perimeter Drive, Ste. 200, Scottsdale, AZ 85255 USA
Tel: 1-480-596-0061, 1-888-205-0093; Fax: 1-480-596-0349
www.iGo.com

As in your car, once connected, your battery will automatically charge regardless of whether your electronic device is turned on or off. Note: We recommend that you use iGo power adapters only with device batteries that meet or exceed the original manufacturer's specifications. CAUTION: Like the power adapter that came with your electronic device, this iGo adapter may get warm to the touch during use. This is normal. Avoid placing your iGo adapter in direct sunlight or next to heat sensitive materials.

Standard Wall Outlet: As in your car, once connected, your battery will automatically charge regardless of whether your electronic device is turned on or off. Note: We recommend that you use iGo power adapters only with device batteries that meet or exceed the original manufacturer's specifications. CAUTION: Like the power adapter that came with your electronic device, this iGo adapter may get warm to the touch during use. This is normal. Avoid placing your iGo adapter in direct sunlight or next to heat sensitive materials.

How to Use This iGo Combination Power Adapter

Your vehicle may need to be running in order to get power. If after checking the connections the LED is still not illuminated, you may need to check the vehicle's fuse. Note: In some vehicles, power to the cigarette lighter is always on. These vehicles may not require the ignition to be turned on. CAUTION: It is not recommended to have this iGo adapter connected to your electronic device when starting the engine. The power may be interrupted causing your system to reset. Air: You will need to find the in-flight power outlet in the airplane. The power outlet is usually located in the arm of your seat, typically near the same location you use to plug in headphones. It may also be located under your seat. Please ask a flight attendant for the exact location of the outlet. Once located, plug the in-flight connector into the airline power outlet.

- Reorient or relocate the receiving antenna
 - Increase the separation between the equipment and receiver
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
 - Consult the dealer or an experienced radio/TV technician for help
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Before installing, please read this important safety information. Proper care of your adapter will ensure its optimal performance.

1. Never pull on the adapter cords. Always hold the plug when inserting or removing it.
2. Select the correct tip for your notebook by reviewing the attached tip compatibility hang tag or going to www.iGo.com – using the wrong tip may damage your computer or cause it to malfunction.
3. Unplug iGo everywhereMAX from the power outlet each time you attach a new tip to the cable.
4. Keep the adapter away from heat sources (such as electric heaters) and avoid direct sunlight exposure.
5. For indoor use only. Keep the adapter free of dust and moisture, and avoid exposure to corrosive chemical (such as cleaning fluids).
6. Do not drop the adapter or subject it to undue shock.
7. Do not place anything on top of the adapter while in use.
8. Turn off the computer and unplug the adapter if you smell something burning or if the adapter becomes overly hot.
9. Do not attempt to disassemble the adapter. It has no serviceable or replaceable parts inside. Voltage in the adapter can cause injury. If the adapter malfunctions, immediately discontinue use and contact iGo Technical Support.
10. Always use the appropriate cables and connectors supplied with your adapter as shown in this User Guide. Use of cables, connectors or other accessories not supplied with your product may result in injury or damage to your device.



1. Connect the **correct** notebook tip to the iGo unit's Notebook Input Cord.

Attention!

Unplug **iGo everywhereMAX** from the power outlet each time you attach a new "tip" to the cable.

Tip Selection:

Make sure you have selected the right tip for the device you want to charge by checking the compatibility hang tag.

Warning:


Choosing the wrong tip may damage your device, causing it to malfunction.

2. Insert the Notebook Input Cord into the **iGo everywhereMAX** body.

3. Select the appropriate power input cord (wall or auto/air) and insert into the **iGo everywhereMAX** body.

4. Plug into the appropriate socket. The LED on the adapter will now illuminate, indicating that power is available. If the LED is not lit, be sure to check all connections. Check *Troubleshooting* for additional information.

5. Plug into the notebook.



iGO[®]
everywhereMAX

Quick Connect Guide

Simultaneously power/charge a notebook computer and a gadget by using the included **iGo dualpower[®] accessory and tips** (additional **iGo power tips sold separately**).

When charging both your notebook and your gadget, plug dualpower into the connection port on the Notebook Input Cord.

Power a gadget from your car, RV or boat using the included auto charging plug and iGo dualpower accessory.


1. Simply press the button on the auto/air outlet cord connector and take off the auto charging plug.
2. Connect the iGo dualpower accessory to the dualpower port on the auto charging plug.

Tech note:


When using iGo dualpower with this iGo adapter, the maximum power output is shared between both devices.

If a device attached to iGo dualpower is not charging properly, it may need more charging power than can be delivered at that particular time.


When this happens, the adapter will shut down (LED will turn off), and we recommend charging each device separately.



Wall Cord



Auto Cord



Wall outlet:
Use as shown.



Auto outlet:
Use as shown.



Important Notice:
Always call your airline to confirm in-flight power seat system availability and specifications for **iGo everywhereMAX** compatibility.

